



# Installation and Operation Manual

Next Generation On-Camera Prompter Displays



Model CSF10-SDI Prompter

# 1 Contents

CueScript CSF10-SDI Prompter .....	6
2 CueScript Prompter Features .....	6
3 Display Technical Specifications .....	6
3.1 Model CSF10-SDI.....	6
4 Signal Inputs.....	6
5 Power Requirements .....	7
6 Dimensions .....	7
7 Environmental.....	7
8 Routine Maintenance .....	7
9 Installation .....	7
9.1 Inspecting New Prompter and Accessories .....	7
9.2 Installation Requirements.....	7
10 Connectors and Controls .....	8
10.1 DC Power .....	8
10.2 Composite Video In and Out .....	9
10.3 VGA.....	9
10.4 SDI.....	9
10.5 USB Out .....	9
11 Operation.....	10
11.1 Control Panel.....	10
11.2 Power Button.....	10
11.3 Rotate Button.....	10
11.4 Menu keys .....	10
11.5 Tally Controls.....	11
11.6 LCD Controller Menu.....	11
12 OSD Menu Layout .....	11
12.1 To enter next level.....	11
12.2 To exit from current level.....	11
13 INFO Menu.....	12
13.1 MODEL.....	12
13.2 INPUT .....	12

13.3	FORMAT.....	12
13.4	COLOR TEMP .....	12
13.5	RANGE .....	12
13.6	VERSION.....	12
14	INPUT Menu.....	13
14.1	RETURN.....	13
14.2	INPUT .....	13
14.3	SETUP LEVEL .....	13
14.4	ANALOG CALIBRATE .....	13
15	PICTURE.....	14
15.1	RETURN.....	14
15.2	BRIGHT.....	14
15.3	CONTRAST .....	14
15.4	CHROMA.....	14
15.5	SHARPNESS.....	14
15.6	GAMMA .....	14
15.7	RESET TO DEFAULT .....	14
16	COLOR .....	15
16.1	RETURN.....	15
16.2	COLOR TEMP .....	15
16.3	BIAS.....	15
16.4	GAIN.....	15
17	SCREEN.....	16
17.1	RETURN.....	16
17.2	SCAN .....	16
17.3	ASPECT.....	16
17.4	MONO/COLOR.....	16
17.5	FLIP H/FLIP V.....	16
18	MARKER .....	17
18.1	RETURN.....	17
18.2	MARKER .....	17
18.3	CENTER .....	17

18.4	ASPECT .....	17
18.5	SAFETY .....	17
18.6	CROSHATCH .....	18
18.7	MARKER MAT .....	18
18.8	LINE THICKNESS .....	18
19	AUDIO .....	18
19.1	RETURN .....	18
19.2	FRONT VOLUME .....	18
19.3	REAR VOLUME(Optional).....	18
20	LEVEL METER .....	18
20.1	What is Audio a Level Meter? .....	18
20.2	LEVEL METER .....	18
21	WAVEFORM .....	19
21.1	What is a Waveform Monitor?.....	19
21.2	RETURN.....	19
21.3	WAVEFORM.....	19
22	VECTORSCOPE.....	20
22.1	What is a Vector Scope?.....	20
22.2	RETURN.....	20
22.3	VECTORSCOPE .....	20
23	ClipGuide.....	21
23.1	RETURN.....	21
23.2	CLIPGUIDE.....	21
23.3	MODE.....	21
23.4	Y UPPER LIMIT .....	21
23.5	Y LOWER LIMIT .....	21
23.6	C UPPER LIMIT .....	21
23.7	C LOWER LIMIT .....	21
24	USER ASSIGN .....	22
24.1	RETURN.....	22
24.2	Available Options.....	22
24.2.1	INPUTS .....	22

24.2.2	Screen Modes .....	22
24.2.3	Screen Modes .....	22
24.2.4	Utility.....	22
24.2.5	Audio.....	22
25	SETUP .....	23
25.1	RETURN.....	23
25.2	FORMAT DISPLAY .....	23
25.3	TIMECODE.....	23
25.4	USERBIT .....	23
25.5	PICTURE DELAY.....	23
25.6	POWER SAVE .....	23
25.7	KEY LOCK.....	23
25.8	BACKLIGHT.....	23
25.9	OSD ALPHA .....	23
25.10	RESET TO DEFAULT .....	24
25.11	BACKUP USER CONFIG.....	24
25.12	RESTORE USER CONFIG .....	24
26	EMC Compliance.....	24
27	CE Declaration.....	24
28	SAFETY INFORMATION .....	24

## CueScript CSF10-SDI Prompter

CueScript was created with a “clean slate” in order to design the most up to date prompters in the industry. These new low profile prompters have all the state of the art features demanded by professional prompter users. A unique dual curved Cue Light window system enhances the ability for all studio personnel to see the active prompter. A quick, no-tools required, mounting system instantly installs the prompter to the mount.

The CueScript CS-10.4 monitor has very high Brightness LED edge-lit screens and delivers superb picture quality.

## 2 CueScript Prompter Features

- Unique quick mount system for simple installation.
- Aluminium case with scratch resistant powder coat finish.
- USB-A 5 Volt DC power out connector for powering external devices.
- Powered by 12V DC.
- Designed for maximum performance with minimum power consumption.
- Instant four-way picture rotate pushbutton switch.
- Picture auto-flip with internal tilt sensor.
- 1500 nit screen for ultra-high brightness picture.
- Internal Tally system with multiple tally light displays
- Tally sensor input with sensitivity control.
- Designed for under camera or direct view prompting.
- SDI input as well as Composite, Component, VGA, and DVI (HDMI).

## 3 Display Technical Specifications

### 3.1 Model CSF10-SDI

<b>Screen Size</b>	10.4 inch diagonal
<b>Display Area</b>	210.432(H) x 157.824(V)mm
<b>Native Resolution</b>	1024 x 768 (XGA)
<b>Brightness</b>	1500 cd/m <sup>2</sup>
<b>Contrast Ratio</b>	900:1
<b>Viewing Angle</b>	160°(H), 160°(V)
<b>Backlight Technology</b>	LED

## 4 Signal Inputs

CueScript CSF10-SDI prompters are designed to accept the most common video signals used in prompting. The following signals are compatible. Please contact CueScript for any special requirements.

- Composite PAL, NTSC, or SECAM Video
- VGA
- DVI (HDMI)
- SDI

- HD Component

## 5 Power Requirements

CueScript CSF10 series prompter monitors are powered with 12 VDC. The maximum power consumed is as follows:

DC 12V      1.2A (14.4W)

## 6 Dimensions

### Outside Dimensions:

**Model CS-10.4:** 254 mm W x 208.4 mm H x 38.1 mm D (10" W X 8.205" H X 1.5" D)

**Weight:** 1.23 kg. 2.7Lb.

## 7 Environmental

All CueScript CSF10 prompter monitors are designed to be operated within the environment specified below.

**Temperature Range:** Operating: 5 to 40 degrees C  
Storage: -20 to 60 degrees C

**Relative Humidity:** 0-95% Non-condensing

## 8 Routine Maintenance

All CueScript prompter monitors are designed to be operated with limited maintenance. Recommended maintenance is as follows:

Remove dust from the cabinet when it accumulates. The front LCD panel may be cleaned with a soft cotton cloth. Use only a small amount of mild soap and water solution to dampen the cloth if necessary.

No routine checks or adjustments are required.

## 9 Installation

### 9.1 Inspecting New Prompter and Accessories

Each item should be inspected as it is unpacked to see if any damage has occurred in shipping. If so, please file a claim with the shipping carrier. Please retain the original packaging in the event it is necessary to reship the unit.

Any missing items should be noted and brought to the attention of the shipper.

### 9.2 Installation Requirements

The following requirements should be observed when installing a CSF10 prompter.

Do not exceed the maximum operating ambient temperature of +40°C .

Do not block any ventilation holes in the prompter cabinet. Free flow of air is required for proper operation.

Use the power supply cord supplied with the unit. Connect the cord to a grounded AC mains outlet.

EMC and Safety Compliance: CSF10 Prompters have been designed for EMC and safety compliance.

However, the installer or operator is responsible for compliance of the system as built and used under the regulations governing such use.

## 10 Connectors and Controls



### 10.1 DC Power

The CueScript CSF10 prompters require a regulated source of 12 VDC that should be capable of supplying approximately 2 amperes. Alternatively, a battery with sufficient capacity may be used.

**Prompter Connector type:** 2.5mm X 5.5mm Male coaxial plug

**Mating (cable) connector:** 2.5mm X 5.5mm Female coaxial socket

Pin	Description
Outer Shell	GROUND (connected to monitor chassis)
Center Pin	+12V DC

## Power Consumption Tables

<b>Model CSF10</b>	<b>Power Consumption @ 12 VDC</b>
1.2A DC	14.4 Watts

10.2 Composite Video In and Out

**Prompter Connector type:** 75 Ohm BNC Socket

**Mating (source) connector:** 75 Ohm BNC Plug

Pin	Description
Center	Composite Video In (PAL,NTSC, or SECAM)
Outer	Ground

10.3 VGA

**Description:** CueScript CSF10 prompters have a PC compatible VGA input. The prompter will automatically scale the input resolution to the screen native resolution.

**Prompter Connector type:** 15 pin High Density D socket

Pin connections are standard VGA.

10.4 SDI

**Description:** CueScript CSF10 prompters have a two SDI BNC input available. The selected input (from the menu) will appear on the BNC SDI output connector as well as the screen. The prompter will automatically scale the input resolution to the screen native resolution.

**Prompter Connector type:** Standard DVI to HDMI Connector (not supplied).

10.5 USB Out

Provides a .5A source of 5 VDC to power accessories. Provides Tally signal to Camera Number system.

**Prompter Connector type:** USB-A (Standard USB)

**Mating (cable) connector:** USB-A (USB) plug

Pin	Description
1	+5 VDC
2	-Tally Repeat
3	+Tally Repeat

4	No Connection
5	Ground

## 11 Operation

### 11.1 Control Panel



There are 6 buttons on the right side of the prompter. Each are described below:

#### 11.2 Power Button

Pressing the power button will turn the monitor on. To turn the monitor off, you must press and hold the power button until the monitor turns off.

#### 11.3 Rotate Button

When the prompter is first turned on, the internal tilt switch will be activated and automatically set the correct image when mounted either in the front facing position or in the under camera prompting position. Tilting the prompter back and forth will cause the image to automatically switch the image orientation. This will continue unless the “Rotate” button is pressed. Once pressed, the image rotation will be in a manual mode and unaffected by the tilt switch. Only turning off the power and turning it back on will re-activate the tilt switch.

Pressing the rotate button will cause the screen to “flip” in both the horizontal way and the vertical way for a total of four possible ways. Successively pressing the rotate button while watching the prompting mirror, allows for a quick set up for proper operation.

#### 11.4 Menu keys

There is a group of four buttons arranged as Up and Down, and Left and Right, with one button in the center. The operation of these buttons for the on-screen display is as follows:

##### MENU

- Activates or deactivates the OSD (On-Screen-Display) menu
- Reverts to one higher level menu page

##### DOWN ARROW

- Moves the OSD selection DOWN one item

#### UP ARROW

- Moves the OSD selection UP one item

#### RIGHT ARROW (+)

- Increments the OSD item value
- Enters into a OSD sub menu
- Stores the new value entered on the OSD

#### LEFT ARROW (-)

- Decrements the OSD item value


### 11.5 Tally Controls

The right side of the prompter has a Sensor jack for a CueScript Tally sensor. A potentiometer is present to adjust the sensitivity of the tally sensor. The USB output connector is designed to connect with the CueScript Tally Number system and provide a camera number and tally system within the CSF10 prompter.

### 11.6 LCD Controller Menu

## 12 OSD Menu Layout

Menu consists of 3 level as below from left to right for deeper level.



#### 12.1 To enter next level

Choose Level1 item and press SELECT key to enter Level2 items.

#### 12.2 To exit from current level

Press MENU key or Choose RETURN menu.

## **13 INFO Menu**

### **13.1 MODEL**

Shows product model name “Venus2 Pro” as default

### **13.2 INPUT**

Shows current selected video input port such as SDI 1 or HDMI

### **13.3 FORMAT**

Shows current detected video format such as 1080/60i

### **13.4 COLOR TEMP**

Shows current selected color temperature such as D65

### **13.5 RANGE**

Shows current digital representation range such as LIMITED or FULL

LIMITED uses 16-235 in 8 bits representation.

FULL uses 0-255 in 8 bits representation.

### **13.6 VERSION**

Shows current firmware version information.

## 14 INPUT Menu

### 14.1 RETURN

Return to Level 1 menu

### 14.2 INPUT

Selects an input port.

- **SDI1:** Selects SDI1 Input, SDI Out will be copy of SDI 1
- **SDI2:** Selects SDI2 Input, SDI Out will be copy of SDI 2
- **HDMI:** Selects HDMI
- **COMP:** Use 3 BNC Input as Component input (Y/Pb/Pr)
- **RGB:** Use 3 BNC Input as RGB input (R/Gs/B)
- **VGA:** Selects VGA port
- **CVBS:** Use 1 BNC input as CVBS (NTSC/PAL)
- **AUTO:** Scans for valid video format on selected ports

### 14.3 SETUP LEVEL


Choose setup level for CVBS input.

**7.5 IRE:** Default value for NTSC-M SMPTE 170M Standard

**0 IRE:** Japanese black level

### 14.4 ANALOG CALIBRATE

Calibrate ADC with 8 COLOR BARS.



**IMPORTANT** 8 ColorBars must contain 8<sup>th</sup> color as BLACK.

Dual confirmation is required to start calibration.

Selects CALIBRATE then move up(or down) and selects for final confirm.

## 15 PICTURE

### 15.1 RETURN

Return to Level 1 menu

### 15.2 BRIGHT

Changes black level at range of 0 to 100.

Default value is **50** for even black level to LCD panel's black.

### 15.3 CONTRAST

Changes video gain at range of 0 to 100.

Default value is **80** for unity gain and maximum dynamic range.

Minimum value 0 shows no video because of gain value at 0.

Maximum value 100 boosts video up with approx. 20% saturation.

### 15.4 CHROMA

Changes Chroma level at range of 0 to 100.

Default value is 50 for standard color representation.

Minimum value 0 shows video in grayscale.

Maximum value 100 shows boosted color approx. 6dB.

### 15.5 SHARPNESS

Changes sharpness level at range of 0 to 100.

Default value is 0 for neutral image processing.

### 15.6 GAMMA

Changes gamma curve at range of 0.45 to 3.00 with 0.05 steps.

Default value is 2.20.

Typical value is between 2.20 and 2.40.

Lower range helps enhancing dark area for easier view.

### 15.7 RESET TO DEFAULT

Resets only picture related values back to default values.

Other values will not be changed.

## 16 COLOR

### 16.1 RETURN

Return to Level 1 menu

### 16.2 COLOR TEMP

Selects color temperature for CIE D65 and Japanese D93.

D65 offers preset 6500K for white balance.

D93 offers preset 9300K for white balance.

USER allows manual adjustment for gain and bias.

Default value is **CIE D65**.

### 16.3 BIAS

Adjusts black level of LCD panels at range of -50 to +50.

Often used to calibrate lower luminance white balance points.

However, leave it as 0 on all channels are recommended for general practice.

Default value is **0** on all channels.

### 16.4 GAIN

Adjusts post processing video gain at range of 0 to 255.

Often used to calibrate higher luminance white balance points.

In general, any channels should not exceed 128.

Use only lower than 128 to avoid unnecessary saturation.

E.g. 120/128/124 for R/G/B

Default value is **128** on all channels.

## 17 SCREEN

### 17.1 RETURN

Return to Level 1 menu

### 17.2 SCAN

- **NORMAL**
  - Displays all valid video region.
  - Also known as JUST SCAN or ZERO SCAN.
- **OVERSCAN**
  - Crop and zoom approx. 5%
- **ZOOM**
  - Crop and zoom at the center of video input for magnification.

### 17.3 ASPECT

- **AUTO**
  - Maintains original aspect ratio.
  - Border may appear according to panel's native aspect ratio.
- **4:3**
  - Forces any video input to 4:3 ratio.
- **16:9**
  - Forces any video input to 16:9 ratio
- **FILL**
  - Forces any video stretch to panel's all valid area.

### 17.4 MONO/COLOR

- **RGB**
  - Displays all three(RGB) channels for normal operation.
- **MONO**
  - Displays video in grayscale.
- **RED/GREEN/BLUE**
  - Displays only one channel at a time for channel verification.

### 17.5 FLIP H/FLIP V

Flips image horizontally and vertically.

## 18 MARKER

Marker is a utility which helps to find center, perpendicular and aspect ratio.

Marker is hidden when OSD menu is displayed.

Marker is hidden when there is no valid input signal.

### 18.1 RETURN

Return to Level 1 menu

### 18.2 MARKER

Enables/Disables marker lines.

### 18.3 CENTER

Enables/Disables center cross marker.

### 18.4 ASPECT

Enables/Disables marker for aspect ratio guide line.

- OFF
- 4:3
- 16:9
- 1.85:1
- 2.35:1
- 4:3&1.85:1
- 4:3&2.35:1

### 18.5 SAFETY

Adjusts margin for safety marker at range from 80% to OFF.

Default value is **80**.

## 18.6 CROSSHATCH

Enables/Disables crosshatch type markers. Crosshatch marker is used for perpendicular guide.

- **OFF(DEFAULT)**
- **SMALL**
- **MEDIUM**
- **LARGE**

## 18.7 MARKER MAT

Choose background type when marker is enabled.

- **CLEAR(DEFAULT)** background is clear
- **HALFTONE** background is half transparent.
- **BLACK** background is opaque black.

## 18.8 LINE THICKNESS

Controls thickness of markers at range from 1 to 3.

[Thin] 1 to 3 [Thick]

Default value is **1** [Thinnest].

## 19 AUDIO

Controls volume for an external speaker if available.

### 19.1 RETURN

Return to Level 1 menu

### 19.2 FRONT VOLUME

Default Volume is **50**.

### 19.3 REAR VOLUME(Optional)

Default Volume is **50**.

## 20 LEVEL METER

### 20.1 What is Audio a Level Meter?

SDI signal can carry embedded audio along video signal.

Often confirmation of audio signal presence is required for various reasons.

Audio level meter offers not only the presence of audio signal but it also displays precisely measured level in dBFS (Decibel in Full Scale).

Venus2 Pro displays audio channel 1 on left and channel 2 on right.


### 20.2 LEVEL METER

Enables/Disables Audio Level Meter for embedded audio from SDI inputs.

## 21 WAVEFORM

### 21.1 What is a Waveform Monitor?

To prevent accidental over exposure (or saturation), engineers need to verify valid range of dynamic range. Waveform monitor helps engineer to determine dynamic range of input signal. It also helps to adjust optical focus on camera shooting.



### 21.2 RETURN

[Return to Level 1 menu](#)

### 21.3 WAVEFORM


Enables/Disables Waveform monitor for video analysis from SDI inputs.

## 22 VECTORSCOPE

### 22.1 What is a Vector Scope?

Conventional TV system limits color reproduction range due to limitation of technical reasons like bandwidth and interference over RF transmit.

VectorScope is designed to verify chrominance range over the content in real time.



### 22.2 RETURN

Return to Level 1 menu

### 22.3 VECTORSCOPE

Enables/Disables VectorScope for video analysis from SDI inputs.

## 23 ClipGuide

Monitor input video range on luminance and chrominance to avoid accidental clipping or saturation. This feature is also known as Zebra but ClipGuide is more enhanced with color and lower/upper thresholds.

### 23.1 RETURN

Return to Level 1 menu

### 23.2 CLIPGUIDE

Enables/Disables ClipGuide feature.

### 23.3 MODE

- **LUMA[Y]**
  - Apply ClipGuide on luminance(Y) channel only
- **Y ON MONO**
  - Apply ClipGuide on luminance(Y) channel only
  - Displays original video content in grayscale for better identification.
- **CHROMA**
  - Apply ClipGuide on chrominance channel only
- **C ON MONO**
  - Apply ClipGuide on chrominance channel only
  - Displays original video content in grayscale for better identification.
- **Y & C**
  - Use both Luminance and Chrominance.
- **Y & C ON MONO**
  - Use both Luminance and Chrominance.
  - Displays original video content in grayscale for better identification.

### 23.4 Y UPPER LIMIT

Sets threshold at range of -7.3 to 109.1 in IRE representation.

Default value is **103.2** in IRE representation.

### 23.5 Y LOWER LIMIT

Sets threshold at range of -7.3 to 109.1 in IRE representation.

Default value is **-0.9** in IRE representation.

### 23.6 C UPPER LIMIT

Sets upper threshold at range of 0 to 255 in 8 bits digital representation.

Default value is **240** in 8bpp representation.

### 23.7 C LOWER LIMIT

Sets lower threshold at range of 0 to 255 in 8 bits digital representation.

Default value is **16** in 8bpp representation.

## 24 USER ASSIGN

Sets user selected feature as a hotkey for specific features.

### 24.1 RETURN

Return to Level 1 menu

### 24.2 Available Options

#### 24.2.1 INPUTS

SDI1/SDI2/CVBS/HDMI/RGB/VGA/COMPONENT

#### 24.2.2 Screen Modes

Rotates available options of each feature.

- **MONO**
- **COLOR**
- **CHANNEL**

#### 24.2.3 Screen Modes

Rotates available options of each feature.

- **SCAN**
- **ASPECT**
- **ZOOM**

#### 24.2.4 Utility

Enables/Disables each feature.

- **MARKER**
- **AUDIO METER**
- **WAVEFORM MON**
- **VECTORSCOPE**
- **ClipGuide**
- **TIMECODE**

#### 24.2.5 Audio

Mutes/Unmutes audio output

- **AUDIO MUTE**

## 25 SETUP

### 25.1 RETURN

Return to Level 1 menu

### 25.2 FORMAT DISPLAY

- **AUTO** – Displays detected video format approx. 5 sec.
- **ON** – Displays detected video format always.
- **OFF** – Does not display detected video format.

Default value is **AUTO**.

### 25.3 TIMECODE

Enables/Disables TIMECODE from SDI signal.

- **OFF** – Does not display timecode from SDI.
- **LTC** – Displays LTC from SDI ANC.
- **VITC1/VITC2** - Displays VITC1 or VITC2 from SDI ANC.

Default value is **OFF**.

### 25.4 USERBIT

Enables/Disables Userbit from SDI

### 25.5 PICTURE DELAY

- **NORMAL** – Enables all video enhancement processing for optimum quality.
- **FAST** – Reduces some video processing for faster picture response.

Default value is **NORMAL**.

### 25.6 POWER SAVE

Enables/Disables power consumption control when there is no valid video signal.

- **ALWAYS ON** – Does not control power saving.
- **OTHER** – Waits for selected period until it goes to sleep.

Default value is **ALWAYS ON**.

Wakes up at any key input or valid video input signal.

### 25.7 KEY LOCK

Prohibits OSD key operation except MENU key.

### 25.8 BACKLIGHT

Controls backlight at range from 0 to 100%.

Default value is 80%.

### 25.9 OSD ALPHA

Controls transparency of OSD menu at range from 0 to 6.

[Opaque] 0 ~ 6 [Transparent]

Default value is **0**.

## 25.10 RESET TO DEFAULT

Restores all setting back to factory standard.

Requires dual confirmation.

## 25.11 BACKUP USER CONFIG

Backs up current setting at where it can be retrieved later.

## 25.12 RESTORE USER CONFIG

Restores backed up setting from where user saved for the last time

## 26 EMC Compliance

The CueScript CSF10 series prompter monitors have been tested by TUV Rhineland and are compliant with the following standards:

### Guidance Documents:

Emissions: EN55103-1:1996

Immunity: EN55103-2:1996

### Test Methods:

Emissions: EN55022:2010 & FCC Part 15

EN61000-3-2:2006 +A1:2009 +A2:2009, EN61000-3-3:2013

Immunity: EN55024:2010,

EN61000-4-2:2009, EN61000-4-3:2006 + A2:2010,

EN61000-4-4:2012, EN61000-4-5:2006, EN61000-4-6:2009,

EN61000-4-8:2010, EN61000-4-11:2004

Meet requirements for VCCI 2010. (Japan)

## 27 CE Declaration



The CueScript CSF10 prompter monitors are compliant with all applicable directives necessary for declaration of conformity. All models are RoHS compliant and all models are have the CE mark affixed.

## 28 SAFETY INFORMATION

The CueScript model CSF10-SDI prompter monitors are not user serviceable. Please return to CueScript in the event that servicing is required. After any servicing, the CueScript service center will re-test each prompter to ensure product safety is intact.

In no event should any modification be made to any CueScript prompter without authorization from CueScript. Doing so without authorization will void the warranty and possibly affect the safety of the product.

Notes:

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

## CUESCRIPT

---

**US OFFICE**

555 Lordship Boulevard  
Stratford  
CT 06615  
**T:** +1(203) 763 4030

**UK OFFICE**

Victoria House  
Harestone Valley Road  
Caterham, Surrey CR3 6HY  
**T:** +44 (0) 20 3757 8880

**24 Hour Support:** +1(203) 692 4856

[support@cuescript.tv](mailto:support@cuescript.tv)

[www.cuescript.tv](http://www.cuescript.tv)